

**Product Brochure For L451** 

Sydney: (02) 9890 9111 Brisbane: (07) 3715 2200 Melbourne: (03) 9212 4422 Perth: (08) 9373 9999

sales@machineryhouse.com.au www.machineryhouse.com.au

# L451 - Lathe Turning Tool Kit - 3 piece Insert Type

16mm Tool Height



EX GS1	inc GS1
\$310.00	\$341.00

ORDER CODE:	L451
Type:	Turning Tool Kit
Tool Type:	Carbide Inserts
Shank Size - Tool Height (mm):	16
Pieces in Set (No.):	3
Replacement Tip Code:	L062
Nett Weight (kg):	1.2







## Description

Compact turning kit with right hand and left hand turning tools and a boring bar. The kit is designed so that all the tools use the same inserts. The inserts used in this kit are ISO standard and can be substituted with any of the major brands of inserts.

16mm Tool Height

## **Includes**

- 1 x 16mm Right hand turning tool STGCR1616H11
- 1 x 16mm Left hand turning tool STGCL1616H11 1 x 16mm Right hand boring bar S16QSTFCR11 10 x inserts to suit all tools(TCMT110204)

## **Optional Accessories**

- Replacement Inserts use (L062)
- Replacement Screw use (L525) Replacement Key T-7 use (L526)



Product Brochure For L451

Sydney: (02) 9890 9111 Brisbane: (07) 3715 2200 Melbourne: (03) 9212 4422 Perth: (08) 9373 9999

sales@machineryhouse.com.au www.machineryhouse.com.au

#### SETTING THE SPINDLE SPEED

To calculate the correct speed the following metric formula can be used

RPM = 
$$\frac{1000 \text{ x Surface speed in Metres per Minute}}{3.14 \text{ x Diameter in millimetres}}$$

 Approximate surface speeds for carbide tools
 Metres per minute

 Material
 Roughing
 Finishing

 Mild Steel
 50
 80

 Cast Iron
 40
 60

 Aluminium
 80
 100

## Example 1.

Stainless Steel

20mm Mild Steel bar to be rough machined

$$RPM = \frac{1000 \times 50}{3.14 \times 20mm} = \frac{50000}{62.8} = 796rpm$$

#### Example 2.

20mm Mild Steel bar to be finished machined

$$RPM = \frac{1000 \times 80}{3.14 \times 20 \text{mm}} = \frac{80000}{62.8} = 1273 \text{rpm}$$

- Set the spindle speed to the closest speed to the RPM calculated
- If in doubt then set a speed slower than the calculated speed

### SETTING THE TOOL ON CENTRE

For the tool to cut correctly it needs to be set on centre. This can be best achieved by placing a centre in the tailstock and packing the tool until the tool is on centre.

Correct centre height



Incorrect centre height

50



## **Specific Features**



Set



Product Brochure For L451

Sydney: (02) 9890 9111 Brisbane: (07) 3715 2200 Melbourne: (03) 9212 4422 Perth: (08) 9373 9999

sales@machineryhouse.com.au www.machineryhouse.com.au

### **Recommended Accessories**

L062

KYOCERA Carbide Inserts - Turning

L525

Screw to Suit Turning Tool Holder

L526

Key to Suit Tool Holder

L017

Right Hand Turning Tool Holder









L018 Left Hand Turning Tool Holder L022

Right Hand Boring Bar

L450

Lathe Turning Tool Kit - 3 piece Insert Type

L452

Lathe Turning Tool Kit - 3 piece Insert Type











Sydney: (02) 9890 9111 Brisbane: (07) 3715 2200 Melbourne: (03) 9212 4422 Perth: (08) 9373 9999

sales@machineryhouse.com.au www.machineryhouse.com.au

## **Product Brochure For L451**

L453

Lathe Turning Tool Kit - 3 piece

L072

HSS Turning Tool Set - 4 piece

L0085

Carbide Turning Tool Set - 11

L0055

Lathe Turning Tool Kit - 5 piece









L0099

Lathe Turning Tool Kit - 7 piece Insert Type

L0077

Lathe Turning Tool Kit - 7 piece Insert Type

L456

Lathe Threading Tool Kit - Insert

L457

Lathe Threading Tool Kit - Insert









L458

Lathe Threading Tool Kit - Insert Type

L459

Lathe Threading Tool Kit - Insert Type

L464

Professional Lathe Parting Tool Kit - Insert Type

L465

Professional Lathe Parting Tool Kit - Insert Type











Sydney: (02) 9890 9111 Brisbane: (07) 3715 2200 Melbourne: (03) 9212 4422 Perth: (08) 9373 9999

sales@machineryhouse.com.au www.machineryhouse.com.au

## Product Brochure For L451

L466

Professional Lathe Parting Tool Kit - Insert Type L467

Professional Lathe Parting Tool Kit - Insert Type L006A

Boring Bar Set - HSS

L431

Boring Bar Set - Carbide Insert



L430 Boring Bar Set - Carbide Insert

