

Product Brochure For L040

## MWLNL-2020-K08 - Left Hand Turning Tool Holder

20mm Tool Height  
 Insert tip not included

**Ex GST**                      **Inc GST**  
**\$100.00**                      **\$110.00**



|             |       |
|-------------|-------|
| ORDER CODE: | L040  |
| Size (mm):  | 20    |
| Hand Type:  | Left  |
| Style:      | MWLNL |
| A (mm):     | 20    |
| B (mm):     | 20    |
| C (mm):     | 125   |
| E (mm):     | ~     |
| F (mm):     | 25    |



### Description

NOTE: Inserts not included with tool holders

Use insert WNMG 080408 (L053)

### Features

- Negative rake turning tool holder suitable for turning and facing
- Suitable for rapid metal removal

### SETTING THE SPINDLE SPEED

To calculate the correct speed the following metric formula can be used

$$\text{RPM} = \frac{1000 \times \text{Surface speed in Metres per Minute}}{3.14 \times \text{Diameter in millimetres}}$$

| Material        | Approximate surface speeds for carbide tools |           |
|-----------------|--|-----------|
|                 | Roughing                                     | Finishing |
| Mild Steel      | 50   | 80        |
| Cast Iron       | 40   | 60        |
| Aluminium       | 80   | 100       |
| Stainless Steel | 40   | 50        |

**Example 1.**  
 20mm Mild Steel bar to be rough machined

$$\text{RPM} = \frac{1000 \times 50}{3.14 \times 20\text{mm}} = \frac{50000}{62.8} = 796\text{rpm}$$

**Example 2.**  
 20mm Mild Steel bar to be finished machined


$$\text{RPM} = \frac{1000 \times 80}{3.14 \times 20\text{mm}} = \frac{80000}{62.8} = 1273\text{rpm}$$

- Set the spindle speed to the closest speed to the RPM calculated
- If in doubt then set a speed slower than the calculated speed

### SETTING THE TOOL ON CENTRE

For the tool to cut correctly it needs to be set on centre. This can be best achieved by placing a centre in the tailstock and packing the tool until the tool is on centre.

Correct centre height



Incorrect centre height



### Specific Features



Side View



Top View


**Recommended Accessories**

**L053**  
 KYOCERA Carbide Inserts -  
 Turning

**L0534**  
 KYOCERA Carbide Inserts -  
 Turning

**L0538**  
 KYOCERA Carbide Inserts -  
 Turning

**L513**  
 Seat to Suit Turning Tool  
 Holders



**L514**  
 Pin to Suit Turning Tool Holders

**L515**  
 Clamp to Suit Turning Tool Holders

**L516**  
 Clamp Screw to Suit Turning  
 Tool Holders

**L450**  
 Lathe Turning Tool Kit - 3 piece  
 Insert Type



Product Brochure For L040

L451

Lathe Turning Tool Kit - 3 piece  
Insert Type



L452

Lathe Turning Tool Kit - 3 piece  
Insert Type



L453

Lathe Turning Tool Kit - 3 piece  
Insert Type



L072

HSS Turning Tool Set - 4 piece



L0085

Carbide Turning Tool Set - 11  
piece



L0055

Lathe Turning Tool Kit - 5 piece  
Insert Type



L0099

Lathe Turning Tool Kit - 7 piece  
Insert Type



L0077

Lathe Turning Tool Kit - 7 piece  
Insert Type



L456

Lathe Threading Tool Kit - Insert  
Type



L457

Lathe Threading Tool Kit - Insert  
Type



L458

Lathe Threading Tool Kit - Insert  
Type



L459

Lathe Threading Tool Kit - Insert  
Type



Product Brochure For L040

L464

Professional Lathe Parting Tool Kit - Insert Type



L465

Professional Lathe Parting Tool Kit - Insert Type



L466

Professional Lathe Parting Tool Kit - Insert Type



L467

Professional Lathe Parting Tool Kit - Insert Type



L006A

Boring Bar Set - HSS



L431

Boring Bar Set - Carbide Insert



L430

Boring Bar Set - Carbide Insert

